

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

609540P POWER SECTIONAL

REVISION 0: 06/17/2020

PAGE 1 OF 14

COASTERFURNITURE.COM

ITEM: 609540LRP ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.

2.Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING! 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION











ITEM: 609540CON ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.

2.Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2.This product is for home use only and not intended for commercial establishment.





2 MINUTES

PARTS IDENTIFICATION



A BACK

B BASE OF CONSOLE



) 1PC

PAGE 4 OF 14

COASTERFURNITURE.COM



ITEM: 609540AC

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.

2.Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
This product is for home use only and not intended for commercial establishment.

COASTER



ITEM: 609540AC ASSEMBLY INSTRUCTIONS



STEP 1



ITEM: 609540WDG

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.

2.Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2.This product is for home use only and not intended for commercial establishment.





5 MINUTES

PARTS IDENTIFICATION





HARDWARE PACKAGE Ζ 1PC LEFT BACK А NO DESCRIPTION FIGURE QTY THREADED RODS **RIGHT BACK** 4PCS В 1PC 1 ⁵/₁₆" * 100mm HEXAGON NUTS С BASE OF WEDGE 4PCS 1PC \bigcirc 2 ⁵⁄₁₆" * 13.5mm LOCK WASHER 4PCS+1PC 3 Õ ⁵/₁₆" * 13mm SPARE FLAT WASHER 4PCS+1PC 4 0 SPARE ⁵/₁₆" * 19mm WRENCH 1PC 5 ⁵⁄16"

PAGE 8 OF 14

COASTERFURNITURE.COM

COA

FINE FURNITU

ITEM: 609540WDG





ITEM: 609540ARP

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.

2.Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishment.

2 MINUTES







ØQ CLOSE OPEN

В BASE

C PLUG-IN POWER SUPPLY



COASTER

FINE FURNITU



PAGE 10 OF 14

COASTERFURNITURE.COM

ITEM: 609540ARP ASSEMBLY INSTRUCTIONS



ITEM : 609540RRP

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.

2.Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION





