



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

609541T
5 PC THEATER SEATING

ITEM :609540LR

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION



A BACK



1 PC

B BASE



1 PC

C LEFT EAR




1 PC


ITEM :609540LR
ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE


STEP 1



STEP 2



STEP 3



ITEM :609540CON
ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION



A BACK



1 PC

B BASE OF CONSOLE




1 PC


ITEM :609540CON
ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE


STEP 1




STEP 2



STEP 3



STEP 4



ITEM :609540AR

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION



A BACK



1 PC

B BASE




1 PC


ITEM :609540AR
ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

STEP 1



STEP 2



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.





WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION**A BACK**

1 PC

B BASE

1 PC


C RIGHT EAR

1 PC


ITEM :609540RR
ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE


STEP 1



STEP 2



STEP 3



609541T

The logo for Coaster Fine Furniture. It features the word "COASTER" in a bold, red, sans-serif font, with a registered trademark symbol (®) at the end. A thick red curved line arches over the top of the letters. Below "COASTER", the words "FINE FURNITURE" are written in a smaller, red, all-caps, sans-serif font.

