



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

609690AC
ARMLESS CHAIR

ITEM :609690AC

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION

A BACK




1 PC

B BASE OF ARMLESS CHAIR





1 PC

STEP 1




STEP 2
COMPLETE




STEP 3


OPTION1:





OPTION2:



STEP 4





Note: Dimension tolerance +5%