



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

609690CON
CONSOLE

ITEM :609690CON

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES


PARTS IDENTIFICATION

A BACK




1 PC

B BASE OF CONSOLE




1 PC


STEP 1





STEP 2



STEP 3




STEP 4
COMPLETE




STEP 5


OPTION1:






OPTION2:



STEP 6





Note: Dimension tolerance +5%