



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

609690WDG
WEDGE

ITEM :609690WDG

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION

A LEFT BACK



1 PC

B RIGHT BACK



1 PC


C BASE OF WEDGE





1 PC

Z	HARDWARE PACKAGE		
NO	DESCRIPTION	FIGURE	QTY
1	THREADED RODS $\frac{5}{16}$ " * 100mm		4PCS
2	HEXAGON NUTS $\frac{5}{16}$ " * 13.5mm		4PCS
3	LOCK WASHER $\frac{5}{16}$ " * 13mm		4PCS+1PC SPARE
4	FLAT WASHER $\frac{5}{16}$ " * 19mm		4PCS+1PC SPARE
5	WRENCH $\frac{5}{16}$ "		1PC

STEP 1




STEP 2
COMPLETE




STEP 3


OPTION1:





OPTION2:



STEP 4





Note: Dimension tolerance +5%