

### ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 06/19/2014 REVISION 1 : 12/17/2018 REVISION 2 : 07/09/2019 REVISION 3 : 01/20/2020 REVISION 4 : 04/27/2022 REVISION 5 : 09/08/2022

PAGE 1 OF 10

COASTERFURNITURE.COM

# ITEM:700112




### **ASSEMBLY INSTRUCTIONS**

#### ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

# WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.




Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


**PAGE 2 OF 10** 


## ITEM:700112


ITEM: <b>/00112</b>						COASTER	
z	HARDWARE IDENTIFICATION					FINE FUR	NITURE
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g	<u>d</u>	1 PC	8	GLIDES L = 350mm WHT	CL	2 SET
2	WOODEN DOWEL Ø 8x30mm		44 PCS	9	SHORT SCREW Ø 3.5x10mm SR		24 PCS
3	CAM BOLT Ø 7x35.5mm SR	and the open states of the second states of the sec	22 PCS	10	HANDLE L=106mm		2 PCS
4	CAM LOCK Ø 15x12mm SR		22 PCS	11	HANDLE BOLT Ø 4x23mm SR		4 PCS
5	LONG BOLT Ø 9.5x55mm SR	and the second second	8 PCS	12	FOOT 100x50x25mm		5 PCS
6	LONG SCREW Ø 4.5x42mm SR	autur .	10 PCS	13	FOOT SCREW Ø 5x22.5mm RBW	and B	10 PCS
7	SCREW Ø 4.3x35mm SR	AND DESCRIPTION OF	8 PCS	14	STICKER Ø 20mm		4 PCS


Z8,Z10,Z12 not included in blister packaging.















### ITEM:700112 STEP 11





**STEP 12** 

