


# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

## 701370 50" TV Console

REVISION 0: 03/06/2011 REVISION 1: 18/03/2020 REVISION 2: 17/08/2023

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




#### WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTE



#### **NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



### **HARDWARE IDENTIFICATION**

1	BOLT (1/4"x1-1/2" - BLK)		2PCS	8	RUBBER BUMPER (ø12mm)		5PCS
2	BOLT (1/4"x7/8" - BLK)		5PCS	9	ANCHORS (WHT)		1PC
3	BOLT 1/4"x1/2" - BLK)		14PCS	10	CONNECTION IRON (WHT)		2PCS
4	PHILLIPS BOLT (3/16"x1/2" - BLK)		4PCS	11	RESTRAINT STRAP (280MM)	D	1PC
5	WASHER (¢16mm - BLK)	0	17PCS	12	SCREW (M4x37mm - WHT)	<b>()</b>	1PC
6	GLASS CLIP (22x18x13 - BLK)		4PCS	13	ALLEN KEY (4x22x60mm - BLK)		1PC
7	ADJUSTABLE LEVEL (5/16"x23mm - BLK)	ER	4PCS				

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


### **ASSEMBLY INSTRUCTIONS**

**STEP 1:** 

#### **ASSEMBLY**

Do not fully tighten all bolts until assembly is complete.


This will help all parts to assemble properly.







3 (1) 4PCS 5 (2) 4PCS


13 🖳




#### **STEP 2:**











### **ASSEMBLY INSTRUCTIONS**








#### **STEP 8:**






# **ASSEMBLY INSTRUCTIONS**

STEP 9:






### TO PREVENT TIP OVER **PRODUCT MUST BE ATTACHED TO WALL**







Note: Dimension tolerance ±5%