COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

701690
COFFEE TABLE 3PCS SET

REVISION 0 : 08/12/2026

ITEM:701690


ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.





WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME | 50 MINUTES



PARTS IDENTIFICATION

A	COFFEE TABLE GLASS TOP		1PC
B	COFFEE TABLE LEFT & RIGHT FRAME		2PCS
C	COFFEE TABLE FRONT & BACK FRAME		2PCS
D	END TABLE GLASS TOP		1PCS

ITEM:701690

ASSEMBLY INSTRUCTIONS

PARTS IDENTIFICATION

E	END TABLE LEFT & RIGHT FRAME		2PCS
F	END TABLE FRONT & BACK FRAME		2PCS

HARDWARE IDENTIFICATION

Z

1	LONG BOLT (1/4" x 47mm)		16PCS
2	SUCTION CUP		10PCS
3	CAP (18 x 18mm)		8PCS
4	COVER		16PCS
5	ALLEN WRENCH (4mm)		1PC


NOTE: QUANTITIES SHOWN ARE FOR ONE COFFEE TABLE AND ONE END TABLE

ITEM:701690


ASSEMBLY INSTRUCTIONS

STEP 1

Do not tighten until each step is completed or instructed.




STEP 2




ITEM:701690


ASSEMBLY INSTRUCTIONS

STEP 3






STEP 4




ITEM:701690


ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6






ITEM:701690


ASSEMBLY INSTRUCTIONS


STEP 7

COMPLETE



ITEM:701690
ASSEMBLY INSTRUCTIONS





Note : Dimension tolerance ±5%