


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

701693
TV STAND

ITEM:701693



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


60 MINUTES

MAX TV SIZE : 85"

PARTS IDENTIFICATION

A


LEFT SIDE
PANEL



1 PC

B


RIGHT SIDE
PANEL



1 PC

C


LEFT MIDDLE
DIVIDER PANEL



1 PC

D


RIGHT MIDDLE
DIVIDER PANEL



1 PC

E


LEFT RIGHT
DIVIDER PANEL



2 PCS

F


LONG
DECORATIVE
STRIP



2 PCS

G


SHORT
DECORATIVE
STRIP



2 PCS

H


BOTTOM PANEL



1 PC

I


ADJUSTABLE
SHELF



1 PC

J


TOP PANEL



1 PC

K


LEFT RIGHT
BACK PANEL



2 PCS

L


MIDDLE BACK
PANEL



1 PC

M

DOOR












4 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:701693

HARDWARE IDENTIFICATION**Z**

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	8	HINGE Ø35mm SR		4 PCS
2	WOODEN DOWEL Ø8 x 30mm		24 PCS	9	HINGE Ø35mm SR		4 PCS
3	CAM BOLT Ø7 x 35.5mm SR		12 PCS	10	HINGE SCREW Ø4x15mm SR		40 PCS
4	CAM LOCK Ø15 x 12mm SR		12 PCS	11	PLASTIC COVER Ø 52mm		1 PC
5	SCREW Ø4.5x42mm SR		24 PCS	12	BACK PANEL SUPPORT		6 PCS
6	PIN FOR ADJUSTABLE SHELF Ø4.9 x 8mm SR		4 PCS	13	BACK PANEL SUPPORT SCREW Ø3 x 19mm SR		6 PCS
7	HANDLE L= 120mm SR		4 PCS	14	STICKER Ø20mm		2 PCS







Z7, Z8, Z9, Z11 not included in blister packaging.

NOTE:



Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 701693

STEP 1






INCORRECT
CORRECT





Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 2






ITEM: 701693

STEP 3




STEP 4




ITEM: **701693**

STEP 5

COASTER
FINE FURNITURE





STEP 6





ITEM: **701693**

STEP 7

COASTER
FINE FURNITURE







STEP 8









ITEM: 701693

STEP 9

COASTER
FINE FURNITURE









STEP 10







ITEM: **701693**

STEP 11

COASTER
FINE FURNITURE






STEP 12




ITEM: **701693**

STEP 13


COASTER
FINE FURNITURE



STEP 14
COMPLETE



ITEM: 701693



Note : Dimension tolerance $\pm 5\%$