

### ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

### 704988 COFFEE TABLE

REVISION 0: 09/12/2017 REVISION 1: 11/09/2022

PAGE 1 OF 5

COASTERFURNITURE.COM



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 28 MINUTES

### PARTS IDENTIFICATION

A	TOP GLASS						1PC
В	BOTTOM HALF MIRROR						1PC
С	SUPPORT FRAME					2PCS	
D	CROSSBAR						4PCS
HARDWARE IDENTIFICATION							
1	BOLT (5/16" x 25mm)		6PCS	4	PLASTIC WASHER (5/16")		6PCS
2	SHORT BOLT (3/16" x 8mm SR)		8PCS	5	SUCTION CUP (ø8mm)		4PCS
3	WASHER (5/16")	0	6PCS	6	FOOT PAD (¢40 x 15mm)		4PCS
PAGE 2 OF 5 COASTERFURNITURE.COM							



7 SPRING WASHER (5/16")

0

6PCS

9 SMALL ALLEN WRENCH (4mm)



1PC


8 LARGE ALLEN WRENCH (5mm)



1PC


STEP 1

Do not tighten until each step is completed or instructed.






STEP 2



### STEP 3




PAGE 4 OF 5

COASTERFURNITURE.COM



**Product Size: 1220 X 610 X 457 H (MM)** 

Product Size: 48" X 24" X 18"



Note: Dimension tolerance ±5%