


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

705397 End Table



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.






ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION





HARDWARE IDENTIFICATION


| 1 | DOWEL | φ8x25mm | | 4pcs |
|---|---------|-----------|----------------------------|-------|
| 2 | CAMBOLT | L29mm | | 24pcs |
| 3 | CAMLOCK | ø15mm | | 24pcs |
| 4 | STICKER | ø20mm(BK) | 0000 0000 | 8pcs |
| 5 | STICKER | ø20mm | 0000 | 8pcs |
| 6 | GLUE | | | 1pc |

ASSEMBLY INSTRUCTIONS


COASTER

COASTERFURNITURE.COM

STEP 1



STEP 2




PAGE 4 OF 6


ASSEMBLY INSTRUCTIONS

ASSEMBET INSTRUCTION

STEP 3








DIMENSION






PAGE 6 OF 6

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

705398 Coffee Table



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.






ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION






HARDWARE IDENTIFICATION

| 1 | DOWEL | Ø8x25mm | | 4pcs |
|---|---------|-----------|----------------------------|-------|
| 2 | CAMBOLT | L29mm | | 24pcs |
| 3 | CAMLOCK | ø15mm | | 24pcs |
| 4 | STICKER | ø20mm(BK) | 0000 0000 | 8pcs |
| 5 | STICKER | ø20mm | 0000 | 8pcs |
| 6 | GLUE | | | 1pc |


ASSEMBLY INSTRUCTIONS

COASTER

STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS

NOOLIIJE! ING!!KOO!!ON

STEP 3



STEP 4




PAGE 5 OF 6

COASTERFURNITURE.COM

DIMENSION





PAGE 6 OF 6

COASTERFURNITURE.COM