COASTER®
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

705617
End Table

REVISION 0 : 05/07/2019
REVISION1 : 04/28/2021
REVISION2 : 11/08/2022

COASTERFURNITURE.COM

ITEM:705617

ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME | 10 MINUTES

PARTS IDENTIFICATION

A	Top		1 PC
B	Right Side Frame		1PC
C	Top Crossbar		2 PCS
D	Bottom Crossbar		2 PCS
E	Left Side Frame		1PC

ITEM:705617

COASTER
FINE FURNITURE

HARDWARE IDENTIFICATION

	DESCRIPTION	FIGURE	Q'TY
1	Short Bolt (M6x12MM)		20 PCS
2	Allen wrench (M4)		1 PC

ITEM:705617

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



ITEM: 705617



Note: Dimension tolerance ±5%

COASTER®
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

705618
Coffee Table

REVISION 0 : 05/07/2019
REVISION 1 : 02/15/2022
REVISION 2 : 02/24/2022
REVISION3 : 11/08/2022
REVISION4 : 04/11/2023

COASTERFURNITURE.COM

ITEM:705618

ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME | 15 MINUTES

PARTS IDENTIFICATION

A	Top		1 PC
B	Right Side Frame		1 PC
C	Top Crossbar		2 PCS
D	Bottom Crossbar		2 PCS
E	Left Side Frame		1PC

ITEM:705618

COASTER FINE FURNITURE

HARDWARE IDENTIFICATION

	DESCRIPTION	FIGURE	Q'TY
1	Short Bolt (M6x12MM)		20 PCS
2	Allen wrench (M4)		1 PC

ITEM:705618

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



ITEM: 705618

COASTER
FINE FURNITURE



Note: Dimension tolerance ±5%