

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

705802
TV STAND

ITEM: 705802



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES

MAX TV SIZE : 65"




PARTS IDENTIFICATION

A	LEFT SIDE PANEL		1 PC	J	LOWER BACK PANEL		1 PC
B	RIGHT SIDE PANEL		1 PC	K	UPPER BACK PANEL		1 PC
C	LOWER DIVIDER PANEL		2 PCS	L	DRAWER FRONT PANEL		2 PCS
D	UPPER DIVIDER PANEL		2 PCS	M	DRAWER BACK PANEL		3 PCS
E	FRONT TOP BAR		2 PCS	N	DRAWER LEFT SIDE PANEL		3 PCS
F	BOTTOM PANEL		1 PC	O	DRAWER RIGHT SIDE PANEL		3 PCS
G	DECORATIVE STRIP		1 PC	P	DRAWER BOTTOM PANEL		3 PCS
H	CROSS PANEL		1 PC	Q	MIDDLE DRAWER FRONT PANEL		1 PC
I	TOP PANEL		1 PC				

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	8	GLIDES L = 350mm BLK		3 SET
2	WOODEN DOWEL Ø8 x 30mm		56 PCS	9	GLIDES SCREW Ø3x12mm BLK		36 PCS
3	CAM BOLT Ø7 x 35.5mm SR		28 PCS	10	PLASTIC COVER Ø 52mm		1 PC
4	CAM LOCK Ø15 x 12mm SR		28 PCS	11	BACK PANEL SUPPORT		6 PCS
5	LONG SCREW Ø 4.5x42mm SR		8 PCS	12	BACK PANEL SUPPORT SCREW Ø3 x 19mm SR		6 PCS
6	SCREW Ø 4.3x35mm SR		12 PCS	13	STICKER Ø20mm		5 PCS
7	PLASTIC FEET Ø15m		6 PCS				





Z8, Z10 not included in blister packaging.

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 705802


STEP 1








INCORRECT
CORRECT



Apply glue on all wooden dowels to ensure integrity of the structure.







STEP 2




ITEM: 705802

COASTER
FINE FURNITURE

STEP 3





INCORRECT
CORRECT




Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 4





↓ the reverse side ↓




ITEM: 705802

COASTER
FINE FURNITURE

STEP 5





INCORRECT
CORRECT




Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 6




ITEM: 705802

STEP 7




STEP 8




ITEM: 705802

STEP 9



STEP 10






ITEM: 705802


COASTER[®]

FINE FURNITURE

STEP 11



STEP 12






ITEM: 705802



COASTER[®]

FINE FURNITURE

STEP 13






STEP 14





ITEM: 705802

COASTER
FINE FURNITURE

STEP 15






STEP 16




ITEM: 705802

STEP 17-1




- 1
- 2 x 12
- 3 x 6

STEP 17-2




- 4 x 6
- 13 x 6

STEP 17-3




STEP 17-4



- 6 x 12


STEP 17-5






- DL DR x 3
- 8
- 9 x 18

ITEM: 705802

STEP 18





STEP 19






ITEM: 705802

STEP 20

COMPLETE





Note : Dimension tolerance $\pm 5\%$