

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

706227
END TABLE

ITEM:706227

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1 PC

B SIDE PANEL



2 PCS

C MIDDLE CROSS
PANEL



1 PC

HARDWARE IDENTIFICATION



Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	WOODEN DOWEL Ø8x30mm		10 PCS	4	PLASTIC FEET Ø15mm		4 PCS
2	CAM BOLT Ø7x35.5mm SR		10 PCS	5	STICKER Ø20mm		2 PC
3	CAM LOCK Ø15x12mm SR		10 PCS				

NOTE:





Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **706227**


STEP 1




STEP 2



x 2



INCORRECT
CORRECT







Apply glue on all wooden dowels to ensure integrity of the structure.





ITEM: **706227**

COASTER
FINE FURNITURE

STEP 3






STEP 4




ITEM: **706227**

STEP 5

COMPLETE



ITEM: **706227**



Note : Dimension tolerance $\pm 5\%$

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

706228
LIFT TOP COFFEE TABLE

ITEM:706228

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!



















1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES

PARTS IDENTIFICATION








A	LEFT SIDE PANEL		1 PC	J	UPPER FRONT AND BACK PANEL		2 PCS
B	RIGHT SIDE PANEL		1 PC	K	TOP PANEL		1 PC
C	MIDDLE DIVIDER PANEL		1 PC	L	BACK PANEL		1 PC
D	UPPER LEFT DIVIDER PANEL		1 PC	M	LEFT DRAWER FRONT PANEL		1 PC
E	UPPER RIGHT DIVIDER PANEL		1 PC	N	DRAWER BACK PANEL		2 PCS
F	LOWER FRONT TOP BAR		2 PCS	O	DRAWER LEFT SIDE PANEL		2 PCS
G	BOTTOM PANEL		1 PC	P	DRAWER RIGHT SIDE PANEL		2 PCS
H	UPPER DECORATIVE STRIP		1 PC	Q	DRAWER BOTTOM PANEL		2 PCS
I	MIDDLE PANEL		1 PC	R	RIGHT DRAWER FRONT PANEL		1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:706228

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		2 PCS	10	SPRING BLK		2 PCS
2	WOODEN DOWEL Ø8 x 30mm		70 PCS	11	BOLT Ø5.8x16mm BLK		12 PCS
3	CAM BOLT Ø7 x 35.5mm SR		38 PCS	12	BOLT M6x19mm BLK		4 PCS
4	CAM LOCK Ø15 x 12mm SR		38 PCS	13	ALLEN WRENCH 4mm SR		1 PC
5	LONG SCREW Ø 4.5x42mm SR		8 PCS	14	WHEEL		5 PCS
6	SCREW Ø 4.3x35mm SR		8 PCS	15	RAIL SCREW Ø 3x15mm SR		20 PCS
7	GLIDES L = 350mm BLK		2 PCS	16	STICKER Ø20mm		7 PCS
8	GLIDES SCREW Ø 3x10mm BLK		24 PCS	17	BOLT M6x28mm BLK		4 PCS
9	LIFTER BLK		1 SET				





Z7, Z9, Z14, Z15 not included in blister packaging.

NOTE:





Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 706228


STEP 1



STEP 2




INCORRECT
CORRECT




Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **706228**

STEP 3




STEP 4




ITEM: **706228**

STEP 5





STEP 6





ITEM: **706228**

COASTER
FINE FURNITURE

STEP 7




STEP 8





ITEM: **706228**

STEP 9




STEP 10




ITEM: **706228**

COASTER
FINE FURNITURE

STEP 11






STEP 12






ITEM: **706228**

COASTER
FINE FURNITURE

STEP 13








STEP 14






ITEM: **706228**

COASTER
FINE FURNITURE

STEP 15







STEP 16






ITEM: **706228**

STEP 17

COASTER
FINE FURNITURE





STEP 18






ITEM: **706228**

STEP 19

COASTER
FINE FURNITURE




STEP 20




ITEM: **706228**

COASTER
FINE FURNITURE


STEP 21-1




STEP 21-2




STEP 21-3



STEP 21-4




STEP 21-5





ITEM: **706228**

STEP 22





STEP 23

COMPLETE



ITEM: 706228



Note : Dimension tolerance $\pm 5\%$