

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

706278
COFFEE TABLE

ITEM: 706278

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1 PC

C LEG PANEL






2 PCS

B MOUNTING PANEL



2 PCS

HARDWARE IDENTIFICATION




Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	WOODEN DOWEL Ø8x30mm		4 PCS	4	ALLEN WRENCH (4mm SR)		1 PC
2	LONG SCREW Ø4.5x42mm SR		12 PCS	5	FLOOR PROTECTOR		4 PCS
3	BOLT Ø7x60mm BLK		6 PCS				

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



ITEM: 706278

STEP 1




Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 2





ITEM: 706278

STEP 3



STEP 4





ITEM: 706278




STEP 5

COMPLETE



ITEM: 706278



Note : Dimension tolerance $\pm 5\%$