



## *ASSEMBLY INSTRUCTIONS*

### *COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**708152**  
**TV CONSOLE**

REVISION 0 : 12/14/2023

PAGE 1 OF 14

COASTERFURNITURE.COM

ITEM:708152



# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



## WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 90 MINUTES MAX TV SIZE: 65"

## PARTS IDENTIFICATION

A


TOP PANEL



1PC

B


LEFT PANEL



1PC

C


RIGHT PANEL



1PC

D


LEFT MIDDLE PANEL



1PC

E

RIGHT MIDDLE PANEL



1PC

ITEM:708152




# ASSEMBLY INSTRUCTIONS

## PARTS IDENTIFICATION

F


LEFT FRONT PANEL



1PC

G


RIGHT FRONT PANEL



1PC

H


BACK PANEL



1PC

I


BACK SUPPORT PANEL



1PC

J


DRAWER FRONT PANEL



1PC

K

DRAWER LEFT PANEL



1PC

ITEM:708152




# ASSEMBLY INSTRUCTIONS

## PARTS IDENTIFICATION

L


DRAWER RIGHT PANEL



1PC

M


DRAWER BACK PANEL



1PC

N


DRAWER BOTTOM PANEL



1PC

O


SHELF PANEL



1PC

P

LEG 1



2PCS

Q

LEG 2




2PCS

# ITEM:708152

## ASSEMBLY INSTRUCTIONS




R MIDDLE FRAME




1PC

S SUPPORT CROSSBAR




1PC

T TOP CROSSBAR




2PCS

U BOTTOM CROSSBAR



2PCS

V HANDLE



1PC

A1 COVER



1PC



















ITEM:708152



# ASSEMBLY INSTRUCTIONS

Z

## HARDWARE IDENTIFICATION


1	CAM BOLT (38mm)		14PCS	10	MEDIUM BOLT (1/4" x 22mm SR)		14PCS
2	CAM LOCK (Ø15mm SR)		14PCS	11	LONG BOLT (1/4" x 47mm SR)		2PCS
3	WOOD DOWEL (8 x 30mm)		32PCS	12	COARSE THREADED BOLT		2PCS
4	WOOD SCREW (8 x 38mm GD)		4PCS	13	LEVELER (1/4" x 12mm)		2PCS
5	HANDLE BOLT (5/32" x 22mm SR)		2PCS	14	HANDLE CAP (16 x 16mm SR)		2PCS
6	SMALL BOLT (5/32" x 12mm SR)		2PCS	15	CAP (13 x 38mm SR)		8PCS
7	SCREW (4 x 25mm SR)		2PCS	16	BOTTOM CAP (13 x 38mm BLK)		4PCS
8	LONG SCREW (4 x 38mm SR)		4PCS	17	GLUE		1PC
9	SHORT BOLT (1/4" x 12mm SR)		16PCS	18	ALLEN WRENCH (4mm)		1PC

# ITEM: 708152 ASSEMBLY INSTRUCTIONS




## STEP 1

Do not tighten until each step is completed or instructed.




## STEP 2




ITEM: 708152

# ASSEMBLY INSTRUCTIONS

## STEP 3



## STEP 4






ITEM:708152




# ASSEMBLY INSTRUCTIONS


## STEP 5




## STEP 6




ITEM: 708152  
ASSEMBLY INSTRUCTIONS  
STEP 7




STEP 8




ITEM: 708152  
ASSEMBLY INSTRUCTIONS  
STEP 9




STEP 10



ITEM: 708152  
ASSEMBLY INSTRUCTIONS  
STEP 11




STEP 12




# ITEM: 708152 ASSEMBLY INSTRUCTIONS





## STEP 13



## STEP 14



COMPLETE





# ITEM: 708152

## ASSEMBLY INSTRUCTIONS



**Product Size : 1524 X 400 X 622 H (MM)**

**Product Size : 60" X 15.75" X 24.5"**



Note : Dimension tolerance  $\pm 5\%$