COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

708537
END TABLE

REVISION 0:03/15/2022
REVISION 1:07/01/2022

COASTERFURNITURE.COM

ITEM:708537 (B1-B2)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME | 10 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A	TOP		1PCS

B2 (BOX 2)

B	TOP FRAME		1PCS
C	BASE		1PCS
D	LEG FRAME		2PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:708537 (B1-B2)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 708537 (B2)

1	ALLEN WRENCH		1PCS
2	SHORT BOLT (M8*50mm)		12PCS
3	FLAT WASHER D20*2		12PCS
4	FRAME REST		6PCS

Hardware pack is located in 708537 B2

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:708537 (B1-B2)

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



STEP 3



STEP 4



ITEM:708537 (B1-B2)



Note : Dimension tolerance ±5%

COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

708538
COFFEE TABLE

REVISION 0:03/15/2022
REVISION 1:07/01/2022

ITEM:708538 (B1-B3)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME | 10 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A	TOP		1PCS

B2 (BOX 2)

B	TOP FRAME		1PCS
C	BASE		1PCS

B3 (BOX 3)

D	LEG FRAME		2PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:708538 (B1-B3)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B3 (BOX 3) - HARDWARE PACK IS LOCATED IN 708538 (B3)

1	ALLEN WRENCH		1PCS
2	SHORT BOLT (M8*50mm)		12PCS
3	FLAT WASHER D20*2		12PCS
4	FRAME REST		8PCS

Hardware pack is located in 708538 B3

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:708538 (B1-B3)

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



STEP 3



STEP 4



COASTERF

ITEM:708538 (B1-B3)



Note : Dimension tolerance ±5%