



# *ASSEMBLY INSTRUCTIONS*

## *COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**709727**  
**END TABLE**

REVISION 0 : 12/04/2023

PAGE 1 OF 9

COASTERFURNITURE.COM

ITEM:709727



# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



## WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 40 MINUTES

## PARTS IDENTIFICATION

A


TOP



1PC

B


TOP CROSSBAR



4PCS

C


BOTTOM CROSSBAR 1



2PCS

D


BOTTOM CROSSBAR 2



2PCS

E

SUPPORT CROSSBAR 1



1PC

ITEM:709727


# ASSEMBLY INSTRUCTIONS

## PARTS IDENTIFICATION




F SUPPORT CROSSBAR 2

1PC



G LEG

4PCS



Z

## HARDWARE IDENTIFICATION

1 SHORT BOLT  
(1/4" x 9mm SR)



21PCS

2 LONG BOLT  
(1/4" x 35mm SR)



8PCS

3 CAP  
(ø18mm BLK)



4PCS

4 SUCTION CUP



4PCS

5 COVER



8PCS

6 ALLEN WRENCH  
(4mm)



1PC


ITEM:709727




# ASSEMBLY INSTRUCTIONS

## STEP 1

Do not tighten until each step is completed or instructed.



## STEP 2




ITEM: 709727




# ASSEMBLY INSTRUCTIONS

## STEP 3




## STEP 4




ITEM: 709727

# ASSEMBLY INSTRUCTIONS


## STEP 5




## STEP 6



ITEM: 709727  
ASSEMBLY INSTRUCTIONS  
STEP 7




STEP 8




ITEM: 709727

# ASSEMBLY INSTRUCTIONS

## STEP 9



## STEP 10 COMPLETE



How to clean Acrylic product:

Using a dry soft microfiber cloth, lightly brush off any dust.

For additional care, dampen the cloth with warm water.

For deepest cleaning, use an Acrylic cleaner.




ITEM:709727

# ASSEMBLY INSTRUCTIONS

**Product Size : 597 X 597 X 559 H (MM)**

**Product Size : 23.5" X 23.5" X 22"**



Note : Dimension tolerance  $\pm 5\%$



*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

709728  
*COFFEE TABLE*

REVISION 0 : 12/04/2023

PAGE 1 OF 9

COASTERFURNITURE.COM

ITEM:709728



# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



## WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 40 MINUTES

## PARTS IDENTIFICATION

A


TOP



1PC

B


TOP CROSSBAR



4PCS

C


BOTTOM CROSSBAR 1



2PCS

D


BOTTOM CROSSBAR 2



2PCS

E

SUPPORT CROSSBAR 1



1PC

ITEM:709728


# ASSEMBLY INSTRUCTIONS

## PARTS IDENTIFICATION




F SUPPORT CROSSBAR 2

1PC



G LEG

4PCS



Z

## HARDWARE IDENTIFICATION

1 SHORT BOLT  
(1/4" x 9mm SR)



21PCS

2 LONG BOLT  
(1/4" x 35mm SR)



8PCS

3 CAP  
(ø18mm BLK)



4PCS

4 SUCTION CUP



4PCS

5 COVER



8PCS

6 ALLEN WRENCH  
(4mm)



1PC


ITEM: 709728




# ASSEMBLY INSTRUCTIONS

## STEP 1

Do not tighten until each step is completed or instructed.




## STEP 2




ITEM: 709728

# ASSEMBLY INSTRUCTIONS

## STEP 3




## STEP 4




ITEM: 709728

# ASSEMBLY INSTRUCTIONS


## STEP 5




## STEP 6



ITEM: 709728  
ASSEMBLY INSTRUCTIONS  
STEP 7



STEP 8






ITEM: 709728




# ASSEMBLY INSTRUCTIONS

## STEP 9



## STEP 10 COMPLETE



How to clean Acrylic product:  
Using a dry soft microfiber cloth, lightly brush off any dust.  
For additional care, dampen the cloth with warm water.  
For deepest cleaning, use an Acrylic cleaner.


# ITEM:709728

## ASSEMBLY INSTRUCTIONS



**Product Size : 900 X 900 X 457 H (MM)**

**Product Size : 35.25" X 35.25" X 18"**



Note : Dimension tolerance  $\pm 5\%$