



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

710488
COFFEE TABLE

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME


10 MINUTES

PARTS IDENTIFICATION



B1: TOP			B2: BASE		
A	TOP		1PC		
B1: HARDWARE					
1	SILICONE GASKET		4PC	B	BASE
					1PC




STEP 2




STEP 3





Note:Dimension tolerance $\pm 5\%$



COASTERFURNITURE.COM