



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

710545 Lift Top Coffee Table

ITEM: **710545**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	TOP		1PC
B	LEG		4PCS
C	BOTTOM SHELF		1PC
D	CASTER		4PCS

HARDWARE IDENTIFICATION

1	LONG BOLT (Ø1/4" x 2" - BLK)		12PCS
2	SHORT BOLT (Ø1/4" x 1 1/4" - BLK)		8PCS
3	LOCK WASHER (Ø1/4" x 16mm - BLK)		20PCS
4	FLAT WASHER (Ø1/4" - BLK)		20PCS
5	ALLEN WRENCH (4mm x 60mm - BLK)		1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **710545**


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




ITEM: **710545**


ASSEMBLY INSTRUCTIONS



STEP 3




STEP 4




ITEM: **710545**

ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6




ITEM: **710545**


ASSEMBLY INSTRUCTIONS



STEP 7





STEP 8 COMPLETE



ITEM: **710545**



Inner Size of Drawer : 7.00"W x 25.50"D X 5.00"H X 0.50"T



Note : Dimension tolerance $\pm 5\%$