


ASSEMBLY INSTRUCTIONS ***COASTER FINE FURNITURE***



Fine Furniture for every stage of life

710767
End Table

ITEM: **710767**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1 PC

B BOTTOM PANEL



1 PC

C SIDE PANEL



2 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:710767



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

D FRONT AND BACK BOTTOM CROSSBAR



2 PCS

E SIDE BOTTOM CROSSBAR






2 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

HARDWARE IDENTIFICATION

1	LARGE CAMBOLT (Ø7 x29mm)		12pcs
2	LARGE CAMBOLT (Ø15x12mm)		12pcs
3	WOOD DOWEL (Ø8 x 40mm)		8pcs
4	SMALL CAMBOLT (Ø6 x20mm)		16pcs
5	SMALL CAMBOLT (Ø12x10mm)		16pcs
6	WOOD DOWEL (Ø6 x 30mm)		4pcs
7	STICKER (Ø22mm)		12pcs

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **710767**




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: **710767**




ASSEMBLY INSTRUCTIONS

STEP 3



X2

STEP 4




ITEM: **710767**




ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6




ITEM: **710767**




ASSEMBLY INSTRUCTIONS

STEP 7



STEP 8




ITEM: **710767**




ASSEMBLY INSTRUCTIONS

STEP 9




STEP 10



ITEM: **710767**




ASSEMBLY INSTRUCTIONS
STEP 11



ITEM: **710767**




DIMENSION



Note: Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS ***COASTER FINE FURNITURE***



Fine Furniture for every stage of life

710768
Coffee Table

ITEM: **710768**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1 PC

B BOTTOM PANEL



1 PC

C SIDE PANEL



2 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:710768



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION


D FRONT AND BACK BOTTOM CROSSBAR

2 PCS



E SIDE BOTTOM CROSSBAR



2 PCS



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

HARDWARE IDENTIFICATION

1	LARGE CAMBOLT (Ø7 x29mm)		12pcs
2	LARGE CAMBOLT (Ø15x12mm)		12pcs
3	WOOD DOWEL (Ø8 x 40mm)		8pcs
4	SMALL CAMBOLT (Ø6 x20mm)		16pcs
5	SMALL CAMBOLT (Ø12x10mm)		16pcs
6	WOOD DOWEL (Ø6 x 30mm)		4pcs
7	STICKER (Ø22mm)		12pcs

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **710768**




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: **710768**




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM: **710768**




ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6




ITEM: **710768**




ASSEMBLY INSTRUCTIONS

STEP 7



STEP 8




ITEM: **710768**




ASSEMBLY INSTRUCTIONS

STEP 9




STEP 10



ITEM: **710768**




ASSEMBLY INSTRUCTIONS
STEP 11



ITEM: **710768**



DIMENSION



Note: Dimension tolerance $\pm 5\%$