COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

710867
End Table

ITEM: **710867**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME	15 MINUTES

PARTS IDENTIFICATION

A	TOP		1PC
B	LEG		4PCS
C	MOUNTING PLATE (PRE-ATTACHED TO TOP)		4PCS

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 100mm - BLK)		1PC
2	BOLT (M6 x 25mm - BLK)		16PCS
3	LOCK WASHER (M6 - BLK)		4PCS
4	FLAT WASHER (M6 - BLK)		4PCS

ITEM: **710867**

ASSEMBLY INSTRUCTIONS

STEP 1

Attention! Please remove part C and all hardware from TOP (A), using ALLEN WRENCH (1) and keep for STEP 3.



STEP 2



ITEM: **710867**

ASSEMBLY INSTRUCTIONS

STEP 3

Attention! Use hardware from STEP 1 for this STEP.



STEP 4



STEP 5

COMPLETE



ITEM: **710867**



Note: Dimension tolerance ±5%

COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

710868
Coffee Table

ITEM: **710868**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME	15 MINUTES

PARTS IDENTIFICATION

A	TOP		1PC
B	LEG		4PCS
C	MOUNTING PLATE (PRE-ATTACHED TO TOP)		4PCS

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 100mm - BLK)		1PC
2	BOLT (M6 x 25mm - BLK)		16PCS
3	LOCK WASHER (M6 - BLK)		4PCS
4	FLAT WASHER (M6 - BLK)		4PCS

ITEM: **710868**

ASSEMBLY INSTRUCTIONS

STEP 1

Attention! Please remove part C and all hardware from TOP (A), using ALLEN WRENCH (1) and keep for STEP 3.



STEP 2



ITEM: **710868**

ASSEMBLY INSTRUCTIONS

STEP 3

Attention! Use hardware from STEP 1 for this STEP.



STEP 4



STEP 5

COMPLETE



ITEM: **710868**



Note: Dimension tolerance ±5%