COASTER®
FINE FURNITURE

# ASSEMBLY INSTRUCTIONS
# COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

## 710978
## COFFEE TABLE

REVISION 0 : 06/01/2026

ITEM:**710978**

# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

**WARNING!**

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME | 30 MINUTES

## PARTS IDENTIFICATION

| | | | |
|---|---|---|---|
| A | LEFT SIDE PANEL |  | 1 PC |
| B | RIGHT SIDE PANEL |  | 1 PC |
| C | MIDDLE DIVIDER PANEL |  | 1 PC |
| D | LONG DECORATIVE STRIP |  | 2 PCS |
| E | SHORT DECORATIVE STRIP |  | 2 PCS |
| F | BOTTOM PANEL |  | 1 PC |
| G | CROSS PANEL |  | 1 PC |
| H | BACK PARTITION PANEL |  | 1 PC |
| I | TOP PANEL |  | 1 PC |
| J | LEFT DRAWER FRONT PANEL |  | 1 PC |
| K | DRAWER BACK PANEL |  | 2 PCS |
| L | LEFT DRAWER SIDE PANEL |  | 2 PCS |
| M | RIGHT DRAWER SIDE PANEL |  | 2 PCS |
| N | DRAWER BOTTOM PANEL |  | 2 PCS |
| O | DRAWER BOTTOM SUPPORT |  | 2 PCS |
| P | RIGHT DRAWER FRONT PANEL |  | 1 PC |

**NOTE:**

**Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.**

ITEM:**710978**

COASTER FINE FURNITURE

# HARDWARE IDENTIFICATION

**Z**

| NO | DESCRIPTION | FIGURE | Q'TY |
|---|---|---|---|
| 1 | GLUE 40g |  | 1 PC |
| 2 | WOODEN DOWEL<br>Ø8x30mm |  | 25 PCS |
| 3 | CAM BOLT<br>Ø7x35.5mm SR |  | 18 PCS |
| 4 | CAM LOCK<br>Ø15x12mm SR | | 18 PCS |
| 5 | SCREW<br>Ø4.5x42mm SR | | 18 PCS |
| 6 | SCREW<br>Ø 4.3x35mm SR | | 10 PCS |

| NO | DESCRIPTION | FIGURE | Q'TY |
|---|---|---|---|
| 7 | HANDLE<br>L= 120mm SR |  | 2 PCS |
| 8 | HINGE SCREW<br>Ø4x15mm SR | | 4 PCS |
| 9 | RAIL<br>L = 350mm BLK |  | 4 PCS |
| 10 | RAIL SCREW<br>Ø3.5x15mm BLK | | 20 PCS |
| 11 | STICKER<br>Ø20mm |  | 3 PCS |

**Z7, Z9 not included in blister packaging.**

**NOTE:**
**Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.**

ITEM:**710978**

COASTER FINE FURNITURE

## STEP 1



















Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**710978**

COASTER FINE FURNITURE

## STEP 2



















Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**710978**

COASTER FINE FURNITURE

## STEP 3







**the reverse side**







INCORRECT
CORRECT



Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**710978**

COASTER FINE FURNITURE

## STEP 4







## STEP 5













Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**710978**

COASTER FINE FURNITURE

## STEP 6




## STEP 7



ITEM:**710978**

COASTER FINE FURNITURE

## STEP 8




## STEP 9



ITEM:**710978**

COASTER FINE FURNITURE

## STEP 10







4 x 8

11 x 8

## STEP 11




5 x 6

ITEM:**710978**

COASTER FINE FURNITURE

## STEP 12







## STEP 13






ITEM:**710978**

## STEP 14






ITEM:**710978**

## STEP 15






ITEM:**710978**

## STEP 16




## STEP 17






ITEM:**710978**

## STEP 18







## STEP 19

**COMPLETE**





ITEM:**710978**










**Note** : Dimension tolerance ±5%

COASTER®
FINE FURNITURE

# ASSEMBLY INSTRUCTIONS
# COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

## 710977
## END TABLE

ITEM:**710977**

# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

**WARNING!**

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME | 30 MINUTES

## PARTS IDENTIFICATION

| | | | |
|---|---|---|---|
| A | LEFT SIDE PANEL |  | 1 PC |
| B | RIGHT SIDE PANEL |  | 1 PC |
| C | LONG DECORATIVE STRIP |  | 2 PCS |
| D | SHORT DECORATIVE STRIP |  | 2 PCS |
| E | BOTTOM PANEL |  | 1 PC |
| F | CROSS PANEL |  | 1 PC |
| G | BACK PARTITION PANEL |  | 1 PC |
| H | TOP PANEL |  | 1 PC |
| I | DRAWER FRONT PANEL |  | 1 PC |
| J | DRAWER BACK PANEL |  | 1 PC |
| K | LEFT DRAWER SIDE PANEL |  | 1 PC |
| L | RIGHT DRAWER SIDE PANEL |  | 1 PC |
| M | DRAWER BOTTOM PANEL |  | 1 PC |

**NOTE:**

**Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.**

ITEM:**710977**

COASTER FINE FURNITURE

# HARDWARE IDENTIFICATION

**Z**

| NO | DESCRIPTION | FIGURE | Q'TY |
|---|---|---|---|
| 1 | GLUE 40g |  | 1 PC |
| 2 | WOODEN DOWEL<br>Ø8x30mm |  | 16 PCS |
| 3 | CAM BOLT<br>Ø7x35.5mm SR |  | 10 PCS |
| 4 | CAM LOCK<br>Ø15x12mm SR | | 10 PCS |
| 5 | SCREW<br>Ø4.5x42mm SR | | 16 PCS |
| 6 | SCREW<br>Ø 4.3x35mm SR | | 4 PCS |

| NO | DESCRIPTION | FIGURE | Q'TY |
|---|---|---|---|
| 7 | HANDLE<br>L= 120mm SR |  | 1 PC |
| 8 | HINGE SCREW<br>Ø4x15mm SR | | 2 PCS |
| 9 | RAIL<br>L = 400mm BLK |  | 2 PCS |
| 10 | RAIL SCREW<br>Ø3.5x15mm BLK | | 10 PCS |
| 11 | STICKER<br>Ø20mm |  | 2 PCS |

**Z7, Z9 not included in blister packaging.**

**NOTE:**
**Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.**

ITEM:**710977**

## STEP 1













INCORRECT
CORRECT






Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**710977**

## STEP 2



















Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**710977**

COASTER FINE FURNITURE

## STEP 3




1

2 x 4

3 x 4

Apply glue on all wooden dowels to ensure integrity of the structure.

## STEP 4




4 x 4

11 x 4

ITEM:**710977**

COASTER FINE FURNITURE

## STEP 5













## STEP 6






ITEM:**710977**

COASTER FINE FURNITURE

## STEP 7







## STEP 8






ITEM:**710977**

## STEP 9






ITEM:**710977**

COASTER FINE FURNITURE

## STEP 10




## STEP 11






ITEM:**710977**

## STEP 12

**COMPLETE**





ITEM:**710977**







**Note** : Dimension tolerance ±5%