COASTER®
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

711017
END TABLE

REVISION 0 : 08/19/2026

ITEM:711017

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME | 25 MINUTES

PARTS IDENTIFICATION

A	TOP PANEL		1PC
B	SIDE PANEL		2PCS
C	BOTTOM PANEL		1PC

ITEM:711017

ASSEMBLY INSTRUCTIONS

Z

HARDWARE IDENTIFICATION

1	CAM-BOLT (38mm)		8PCS
2	CAM-LOCK (ϕ15mm)		8PCS
3	BOLT (1/4" x 28mm)		8PCS
4	LARGE LEVELER (1/4" x 12mm)		4PCS
5	ALLEN WRENCH (4mm)		1PC

STEP 1



ITEM:711017

ASSEMBLY INSTRUCTIONS

STEP 2



STEP 3



ITEM:711017

ASSEMBLY INSTRUCTIONS

STEP 4



STEP 5

COMPLETE



ITEM:711017

ASSEMBLY INSTRUCTIONS



Note : Dimension tolerance ±5%

COASTER®
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

711018
COFFEE TABLE

REVISION 0 : 08/19/2026

ITEM:711018

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME | 30 MINUTES

PARTS IDENTIFICATION

A	TOP PANEL		1PC
B	SIDE PANEL		2PCS
C	BOTTOM PANEL		1PC

ITEM:711018

ASSEMBLY INSTRUCTIONS

Z

HARDWARE IDENTIFICATION

1	CAM-BOLT (38mm)		8PCS
2	CAM-LOCK (ϕ15mm)		8PCS
3	BOLT (1/4"x 28mm)		8PCS
4	LARGE LEVELER (1/4" x 12mm)		5PCS
5	ALLEN WRENCH (4mm)		1PC

STEP 1



ITEM:711018

ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE

STEP 2



STEP 3



ITEM:711018

ASSEMBLY INSTRUCTIONS

STEP 4



STEP 5

COMPLETE



ITEM:711018

ASSEMBLY INSTRUCTIONS



Note : Dimension tolerance ±5%