



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

711018
COFFEE TABLE

REVISION 0 : 08/19/2026

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM:711018



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 30 MINUTES

PARTS IDENTIFICATION

A


TOP PANEL



1PC

B


SIDE PANEL



2PCS

C

BOTTOM PANEL



1PC


ITEM:711018




ASSEMBLY INSTRUCTIONS

Z

HARDWARE IDENTIFICATION

1	CAM-BOLT (38mm)		8PCS	4	LARGE LEVELER (1/4" x 12mm)		5PCS
2	CAM-LOCK (ϕ 15mm)		8PCS	5	ALLEN WRENCH (4mm)		1PC
3	BOLT (1/4"x 28mm)		8PCS				


STEP 1




ITEM: 711018

ASSEMBLY INSTRUCTIONS

STEP 2



STEP 3




ITEM: 711018





ASSEMBLY INSTRUCTIONS

STEP 4




STEP 5

COMPLETE



ITEM:711018

ASSEMBLY INSTRUCTIONS



Note : Dimension tolerance $\pm 5\%$