

ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

SOFA TABLE

722519

REVISION 0: 11/07/2019 REVISION 1: 5/07/2020 REVISION 2: 4/03/2023

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 722519

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME


10 MINUTES

PARTS IDENTIFICATION

Z-HARDWARE


B1: TOP	MIRROR CAB	INET 1PC	1	BOLT 8x35MM	16PCS
C	BASE	1PC	2	WASHER Φ20x2MM	16PCS
B2: BASE				\$20X2IVIIVI	
В	LEG	2PCS	3	ALLEN KEY 30x80MM	1PC

HARDWARE PACK IS LOCATED IN 722519 (B1)



ITEM: 722519







COASTERFURNITURE.COM

Note: Dimension tolerance $\pm 5\%$