

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

723448
SOFA TABLE

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.






ASSEMBLY TIME


10 MINUTES

PARTS IDENTIFICATION


Z-HARDWARE

B1: TOP			1PC	1	SILICONE GASKET		4PC			
A	TOP									
B2: BASE			1PC					HARDWARE PACK IS LOCATED IN 723448 (B1)		
B	BASE									



ITEM : 723448
ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2




STEP 3





Note:Dimension tolerance $\pm 5\%$



COASTERFURNITURE.COM