

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

723487 <u>End Table</u>

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A TOP 1PC

B SHELF 1PC

C LEG 4PCS


HARDWARE IDENTIFICATION

1	BOLT (5/16 x 50mm - BLK)		12PCS
2	LOCK WASHER (1.6 x 14mm - BLK)	•	12PCS
3	FLAT WASHER (2 x 19mm - BLK)		12PCS
4	ALLEN WRENCH (M5 x 65mm - BLK)		1PC


ASSEMBLY INSTRUCTIONS

COASTER

STEP 1



STEP 2




ASSEMBLY INSTRUCTIONS



STEP 3


ATTENTION!

Do not fully tighten bolts in this step.



STEP 4


Please tighten bolts 100% after assembly is complete.




ASSEMBLY INSTRUCTIONS

STEP 5






STEP 6 COMPLETE









Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

723488 Coffee Table

REVISION 0: 08/27/2025

PAGE 1 OF 5

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.



BOLT

ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A TOP

B SHELF

1PC

4PCS


HARDWARE IDENTIFICATION

1	(5/16 x 50mm - BLK)	12PCS
2	LOCK WASHER (1.6 x 14mm - BLK)	12PCS
3	FLAT WASHER (2 x 19mm - BLK)	12PCS
4	ALLEN WRENCH (M5 x 65mm - BLK)	1PC


ASSEMBLY INSTRUCTIONS

STEP 1





STEP 2



PAGE 3 OF 5

COASTERFURNITURE.COM


ASSEMBLY INSTRUCTIONS



STEP 3


ATTENTION!

Do not fully tighten bolts in this step.



STEP 4


Please tighten bolts 100% after assembly is complete.




ASSEMBLY INSTRUCTIONS

STEP 5






STEP 6 COMPLETE



凉

COASTERFURNITURE.COM





Note: Dimension tolerance ±5%