


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

753390 **3PC Set**

REVISION 0:05/11/2020

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



1. Remove hardware from box and sort by size.

2. Please check to see that all hardware and parts are present prior to start of assembly.

Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
 This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION


A	BIG LEG	445*265mm	2PCS
В	SMALL LEG	545*140mm	4PCS
С	BIG FRAME	536*445mm	2PCS
D	SMALL FRAME	440*545mm	4PCS
Е	BIG TOP		1PC
F	SMALL TOP	1070*560mm 460*460mm	2PCS




	Z HARDWARE IDENTIFICATION		
	DESCRIPTION	FIGURE	Q'TY
1	SHORT BOLT		18PCS
2	LONG BOLT M6×35		12PCS
3	ALLEN WRENCH		1PC

ASSEMBLY INSTRUCTIONS






STEP 2




COASTER

ASSEMBLY INSTRUCTIONS

STEP 3




STEP4






STEP5



STEP6



PAGE 6 OF 7

COASTERFURNITURE.COM



