


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

753398
Coffee Table

ITEM: 753398



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES



PARTS IDENTIFICATION

No	DESCRIPTION & FIGURE	QTY
A	TOP 	1pc
B	LEG 1 	2pcs
C	LEG 2 	2pcs
D	LEG SUPPORT 	2pcs


HARDWARE PACKAGE:

No	DESCRIPTION	FIGURE	QTY
1	CAM BOLT 		8pcs
2	COM LOCK 		8pcs
3	BOLT  M8x30mm		8pcs
4	WASHER  Ø20xØ8x1.2mm		8pcs
5	ALLEN KEY (5mm) 		1pc

STEP 1




STEP 2





ITEM: **753398**




STEP 3



STEP 4
COMPLETE



ITEM: **753398**



Note: Dimension tolerance $\pm 5\%$