COASTER®
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

800870
WRITING DESK

ITEM:**800870**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:
















1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME | 30 MINUTES

PARTS IDENTIFICATION

A	LARGE TOP PANEL		2 PCS
B	SMALL TOP PANEL		1 PC
C	BOTTOM SHELF		1 PC
D	DRAWER FRONT PANEL		2 PCS
E	DRAWER BACK PANEL		2 PCS
F	DRAWER LEFT SIDE PANEL		2 PCS
G	DRAWER RIGHT SIDE PANEL		2 PCS
H	DRAWER BOTTOM PANEL		2 PCS
I	SIDE LEG FRAME		2 PCS
J	MIDDLE LEFT LEG FRAME		1 PC
K	MIDDLE RIGHT LEG FRAME		1 PC
L	LONG LOWER CROSS BRACE		2 PCS
M	LONG UPPER CROSS BRACE		4 PCS
N	SHORT LOWER CROSS BRACE		2 PCS
O	SHORT UPPER CROSS BRACE		2 PCS

NOTE:





Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




ITEM:**800870**

COASTER FINE FURNITURE

HARDWARE IDENTIFICATION

Z

NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC
2	WOODEN DOWEL Ø8x30mm		8 PCS
3	CAM BOLT Ø7x35.5mm SR		4 PCS
4	CAM LOCK Ø12x11mm SR		4 PCS
5	SCREW Ø4.3x35mm SR		8 PCS
6	RAIL L= 350mm BLK		4 PCS
7	RAIL SCREW Ø3.5x15mm BLK		12 PCS
8	RAIL BOLT M4x15mm BLK		4 PCS

NO	DESCRIPTION	FIGURE	Q'TY
9	HANDLE BLK		2 PCS
10	HANDLE BOLT Ø4x25mm BLK		2 PCS
11	SCREW Ø4.3x38mm SR		16 PCS
12	BOLT M6x43mm BLK		20 PCS
13	HOOK		4 PCS
14	ALLEN WRENCH 4mm SR		1 PC
15	PLASTIC FEET Ø30x12mm		8 PCS
16	STICKER Ø20mm		1 SHEET (6 COVERS)


Z6, Z13, Z15 not included in blister packaging.

NOTE:
Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM:**800870**

COASTER FINE FURNITURE

STEP 1




STEP 2




ITEM:**800870**


COASTER FINE FURNITURE


STEP 3






STEP 4










ITEM:**800870**

COASTER FINE FURNITURE


STEP 5









STEP 6










ITEM:**800870**

COASTER FINE FURNITURE


STEP 7









STEP 8









ITEM:**800870**

COASTER FINE FURNITURE

STEP 9





STEP 10




ITEM:**800870**

STEP 11








ITEM:**800870**

COASTER FINE FURNITURE


STEP 12




ITEM:**800870**


COASTER FINE FURNITURE

STEP 13



STEP 14







ITEM:**800870**

COASTER
FINE FURNITURE


STEP 15






STEP 16


COMPLETE








ITEM:**800870**





Note : Dimension tolerance ±5%