



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0:06/26/2026

902869GLD
SNACK TABLE

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM:902869GLD



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 20 MINUTES

PARTS IDENTIFICATION

A	TOP GLASS		1PC
B	LEG CONNECTOR		1PC
C	LEG		3PCS


HARDWARE IDENTIFICATION

1	SMALL BOLT (1/4"x10mm SR)		3PCS	4	ROUND CAP (φ 25mm SR)		2PCS
2	LARGE BOLT (1/4"x25mm SR)		3PCS	5	ALLEN WRENCH (4mm)		1PC
3	CAP (20x20mm SR)		3PCS				


ITEM:902869GLD ASSEMBLY INSTRUCTIONS




STEP 1 Do not tighten until each step is completed or instructed.



STEP 2



COMPLETE




ITEM:902869GLD ASSEMBLY INSTRUCTIONS



Product Size : 457 DIA X 578 H (MM)
--

Product Size : 18" DIA X 22.75"
--



Note : Dimension tolerance $\pm 5\%$