



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

903082

ACCENT CHAIR

REVISION 0:13/07/2023

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM:903082



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don' t attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

3 MINUTES


PARTS IDENTIFICATION

A CHAIR



1PC

B LEG



4PCS

HAREWARE IDENTIFICATION


1 WASHER



Ø0.6CM

8 PCS

3 BOLT



6*30MM

8 PCS


2 WRENCH




Ø0.6CM

1 PC


STEP 1



STEP 2



STEP 2



Note: Dimension tolerance $\pm$ 5%