



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

903162
ACCENT CHAIR

REVISION 0 : 12/12/2023

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM:903162



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.







WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 40 MINUTES

PARTS IDENTIFICATION

A	CUSHION 1		4PCS
B	CUSHION 2		2PCS
C	BASE ARCYLIC		1PC
D	BACK ARCYLIC		1PC

Z

HARDWARE IDENTIFICATION

1	SHORT BOLT (1/4" x 18mm SR)		4PCS	3	NUT		4PCS
2	LONG BOLT (1/4" x 35mm SR)		12PCS	4	ALLEN WRENCH (4mm)		1PC


ITEM:903162




ASSEMBLY INSTRUCTIONS

STEP 1

Do not tighten until each step is completed or instructed.




STEP 2




ITEM:903162

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4




ITEM:903162

ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6 COMPLETE




How to clean Acrylic product:

Using a dry soft microfiber cloth, lightly brush off any dust.

For additional care, dampen the cloth with warm water.

For deepest cleaning, use an Acrylic cleaner.




ITEM:903162

ASSEMBLY INSTRUCTIONS



Product Size : 641 X 800 X 743 H (MM)

Product Size : 25.25" X 31.5" X 29.25"



Note : Dimension tolerance $\pm 5\%$