



ASSEMBLY INSTRUCTIONS *COASTER FINE FURNITURE*



Fine Furniture for every stage of life

REVISION 0 : 07/31/2026

903236
Accent Chair

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM: 903236




ASSEMBLY INSTRUCTIONS

- ASSEMBLY TIPS:**
- 1. Remove hardware from box and sort by size.
 - 2. Please check to see that all hardware and parts are present prior start of assembly.
 - 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



- WARNING!**
- 1. Don't attempt to repair or modify parts that are broken or defective .Please contact the store immediately.
 - 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A.		CHAIR BACK	1PC
B.		SEAT CUSHION	1PC
C.		SEAT FRAME	1PC
D.		LEFT ARM	1PC
E.		RIGHT ARM	1PC
F.		PILLOW	1PC


Z HARDWARE IDENTIFICATION

1	ALLEN KEY M5mm		1PC
2	BOLTØ5/16""*3-1/4"		4PCS
3	BOLTØ5/16""*2-1/4"		4PCS
4	BOLTØ5/16""*1-3/4"		2PCS
5	SPRING WASHER-BIG Ø5/16"		10PC
6	FLAT WASHER-BIG Ø5/16""*22mm		10PCS
7	ALLEN KEY M4mm		1PC
8	BOLTØ1/4""*1-3/4"		2PCS
9	SPRING WASHER-BIG Ø1/4		2PC
10	WOODEN CAP 14*7mm		2PC
11	WOODEN DOWEL 10*30mm		2PC


ITEM: 903236

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



ITEM: 903236
ASSEMBLY INSTRUCTIONS
STEP 3



STEP 4



ITEM: 903236
ASSEMBLY INSTRUCTIONS
STEP 5

