

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

## 905614 ACCENT CHAIR

PAGE 1 OF 3

# ITEM: 905614 ASSEMBLY INSTRUCTIONS



**COASTERFURNITURE.COM** 

### **ASSEMBLY TIPS**

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1.Don't attempt to repair or modify parts that are broken or defective.Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.


### PARTS IDENTIFICATION


PARTS IDENTIFICATION			
A		SEAT	1PC
В		BACK	1PC
С		FRONT LEG FRAME	1PC
D		BACK LEG FRAME	1PC
E	(o o)	CROSSBAR	2PCS
Z HARDWARE IDENTIFICATION			
1		BOLT (M6x40MM)	9PCS
2		ALLEN WRENCH (M5)	1PC

PAGE 2 OF 3


## ITEM: 905614


### **ASSEMBLY INSTRUCTIONS**















# ITEM: 905614 ASSEMBLY INSTRUCTIONS





Noted: Dimension tolerance ±5%