

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

909478 ACCENT CHAIR

REVISION 0: 07/15/2022

COASTERFURNITURE.COM

ITEM: 909478

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 10 MINUTES

PARTS IDENTIFICATION

BASE 1PC


BACK CUSHION 1PC

C LEG 4PCS

ITEM: 909478 **ASSEMBLY INSTRUCTIONS** STEP 1 A < STEP 2 С STEP 3 B ← STEP 4







Note: Dimension tolerance ±5%

COASTERFURNITURE.COM