



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

930134
SIDE TABLE

REVISION 0 : 08/19/2026

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM:930134



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION

A


TOP



1PC

B


TOP FRAME



1PC

C


PEDESTAL



1PC

D


BASE COVER



1PC

E

BASE



1PC

ITEM:930134



ASSEMBLY INSTRUCTIONS

Z

HARDWARE IDENTIFICATION

1 BOLT
(1/4" x 12mm SR)



4PCS

4 WASHER



1PC

2 LONG BOLT
(5/16" x 70mm SR)



1PC

5 ALLEN WRENCH
(4mm)



1PC

3 SCREW




4PCS

6 LARGE ALLEN WRENCH
(5mm)




1PC

STEP 1




STEP 2



ITEM:930134


ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4

COMPLETE



ITEM:930134

ASSEMBLY INSTRUCTIONS



Note : Dimension tolerance $\pm 5\%$