



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

930135
SIDE TABLE

REVISION 0 : 08/19/2026

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM:930135



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION

A


TOP



1PC

B

LEG



3PCS

C

LEG SUPPORT



3PCS

ITEM:930135

ASSEMBLY INSTRUCTIONS



Z

HARDWARE IDENTIFICATION

- 1 BOLT
(1/4" x 28mm SR)



3PCS

- 3 CAP
(18 x 18mm)



6PCS

- 2 SMALL BOLT
(1/4" x 12mm SR)




6PCS

- 4 ALLEN WRENCH
(4mm)



1PC

STEP 1




ITEM:930135




ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4

COMPLETE



ITEM:930135

ASSEMBLY INSTRUCTIONS



Note : Dimension tolerance $\pm 5\%$