

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

931146 *ACCENT TABLE*

REVISION 0:06/03/2019 REVISION 1:05/09/2023

PAGE 1 OF 5

COASTERFURNITURE.COM



COASTERFURNITURE.COM

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 35 MINUTES

PARTS IDENTIFICATION


A	ТОР						1PC
В	TOP FRAME	TOP FRAME					
С	BOTTOM FRAME						1PC
D	LEG						2PCS
E	SUPPORT LEG						
HARDWARE IDENTIFICATION							
1 (SMALL BOLT (3/16" x 12mm BLK)		6PCS	4	SCREW (8# x 1-1/4" BLK)	Day Day	4PCS
2	SHORT BOLT (1/4" x 22mm BLK)		2PCS	5	SUCTION CUP (¢6.3mm)		4PCS
3	LONG BOLT (1/4" x 38mm BLK)		2PCS	6	ALLEN WRENCH (4mm)		1PC

PAGE 2 OF 5




STEP 1

Do not tighten until each step is completed or instructed.



STEP 2




PAGE 3 OF 5


COASTERFURNITURE.COM



STEP 3



STEP 4 COMPLETE




PAGE 4 OF 5

COASTERFURNITURE.COM



Product Size: 254 X 457 X 635 H (MM)

Product Size: 10" X 18" X 25"



Note: Dimension tolerance ±5%