

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

950443
WARDROBE CABINET

ITEM:950443

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

90 MINUTES





PARTS IDENTIFICATION








NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **950443**







O	DRAWER LEFT SIDE PANEL		1 PC	R	DRAWER BOTTOM SUPPORT		1 PC
P	DRAWER RIGHT SIDE PANEL		1 PC	S	BOTTOM SUPPORT PANEL		2 PCS
Q	DRAWER BOTTOM PANEL		1 PC				

HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	6	SCREW Ø 4.3x35mm SR		5 PCS
2	WOODEN DOWEL Ø8x30mm		42 PCS	7	PLASTIC FEET Ø15mm		5 PCS
3	CAM BOLT Ø7x35.5mm SR		27 PCS	8	DOOR CATCH		2 PCS
4	CAM LOCK Ø15x12mm SR		27 PCS	9	HINGE Ø35mm SR		6 PCS
5	SCREW Ø4.5x42mm SR		12 PCS	10	HINGE SCREW Ø4x15mm SR		24 PCS

ITEM:950443

Z

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
11	HANDLE L= 170mm SR		3 PCS	15	RUBBER Ø 58mm BLK		1 PC
12	BOLT M4x25mm SR		6 PCS	16	BACK PANEL SUPPORT		6 PCS
13	RAIL L = 350mm BLK		2 PCS	17	BACK PANEL SUPPORT SCREW Ø3x19mm SR		6 PCS
14	RAIL SCREW Ø3.5x15mm BLK		10 PCS	18	STICKER Ø20mm		5 PCS

Z9, Z11, Z12, Z13, Z15 not included in blister packaging.


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **950443**


COASTER
FINE FURNITURE

STEP 1




ITEM:950443

STEP 2




ITEM: **950443**

STEP 3




STEP 4




ITEM: **950443**

STEP 5





STEP 6






ITEM: **950443**

STEP 7

COASTER
FINE FURNITURE





STEP 8



ITEM: **950443**






STEP 9

COASTER
FINE FURNITURE





ITEM: **950443**

STEP 10




STEP 11



ITEM:950443



STEP 12



ITEM: **950443**

STEP 13





COASTER
FINE FURNITURE




ITEM: **950443**

STEP 14


COASTER
FINE FURNITURE



STEP 15
COMPLETE



ITEM: 950443



Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT


WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.



STEP 2

Locate the wood stud on the wall, and secure the other bracket, 2 inches below the back of the unit.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end, and drag it through, until the slack is removed. Ensure that the strap is securely laced and locked.

