


**ASSEMBLY INSTRUCTIONS**  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**950448BLK**  
**WARDROBE CABINET**

# ITEM:950448BLK



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!


















1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

90 MINUTES












## PARTS IDENTIFICATION

|   |                   |                                                                                     |       |   |                        |                                                                                       |       |
|---|-------------------|-------------------------------------------------------------------------------------|-------|---|------------------------|---------------------------------------------------------------------------------------|-------|
| A | LEFT SIDE PANEL   |    | 1 PC  | J | BACK PARTITION PANEL   |    | 1 PC  |
| B | RIGHT SIDE PANEL  |    | 1 PC  | K | LEFT UPPER BACK PANEL  |    | 1 PC  |
| C | DIVIDER PANEL     |   | 1 PC  | L | LEFT MIDDLE BACK PANEL |   | 1 PC  |
| D | CROSS BRACE       |  | 2 PCS | M | LEFT LOWER BACK PANEL  |  | 1 PC  |
| E | BOTTOM PANEL      |  | 1 PC  | N | RIGHT UPPER BACK PANEL |  | 1 PC  |
| F | LEFT CROSS PANEL  |  | 1 PC  | O | RIGHT LOWER BACK PANEL |  | 1 PC  |
| G | RIGHT CROSS PANEL |  | 1 PC  | P | DOOR                   |  | 3 PCS |
| H | ADJUSTABLE SHELF  |  | 2 PCS | Q | BOTTOM SUPPORT PANEL   |  | 2 PCS |
| I | TOP PANEL         |  | 1 PC  |   |                        |                                                                                       |       |

### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **950448BLK****HARDWARE IDENTIFICATION****Z**

| NO | DESCRIPTION                                | FIGURE                                                                              | Q'TY   | NO | DESCRIPTION                               | FIGURE                                                                                | Q'TY   |
|----|--------------------------------------------|-------------------------------------------------------------------------------------|--------|----|-------------------------------------------|---------------------------------------------------------------------------------------|--------|
| 1  | GLUE 40g                                   |    | 1 PC   | 10 | HINGE SCREW<br>Ø4x15mm SR                 |    | 40 PCS |
| 2  | WOODEN DOWEL<br>Ø8x30mm                    |    | 42 PCS | 11 | HANDLE<br>L= 289mm BLK                    |    | 3 PCS  |
| 3  | CAM BOLT<br>Ø7x35.5mm SR                   |    | 18 PCS | 12 | BOLT<br>M4x28mm BLK                       |    | 6 PCS  |
| 4  | CAM LOCK<br>Ø15x12mm SR                    |    | 18 PCS | 13 | RUBBER<br>Ø 58mm BLK                      |    | 3 SETS |
| 5  | SCREW<br>Ø4.5x42mm SR                      |  | 24 PCS | 14 | DOOR CATCH                                |  | 1 PC   |
| 6  | PLASTIC FEET<br>Ø15mm                      |  | 6 PCS  | 15 | BACK PANEL<br>SUPPORT                     |  | 6 PCS  |
| 7  | PIN FOR<br>ADJUSTABLE SHELF<br>Ø4.9x8mm SR |  | 8 PCS  | 16 | BACK PANEL<br>SUPPORT SCREW<br>Ø3x19mm SR |  | 6 PCS  |
| 8  | ROD HOLDER                                 |  | 2 PCS  | 17 | STICKER<br>Ø20mm                          |  | 3 PCS  |
| 9  | HINGE<br>Ø35mm SR                          |  | 9 PCS  | 18 | HANGING ROD<br>L= 740mm SR                |  | 1 PC   |








**Z8, Z9, Z11, Z13, Z18 not included in blister packaging.****NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **950448BLK**

**STEP 1**

**COASTER**  
FINE FURNITURE








Apply glue on all wooden dowels to ensure integrity of the structure.


ITEM: **950448BLK**

**STEP 2**


**COASTER**  
FINE FURNITURE



the reverse side





INCORRECT  
CORRECT






Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **950448BLK**

**STEP 3**



**STEP 4**





Apply glue on all wooden dowels to ensure integrity of the structure.






ITEM: **950448BLK**

**COASTER**  
FINE FURNITURE

## STEP 5



## STEP 6




Apply glue on all wooden dowels to ensure integrity of the structure.



ITEM: **950448BLK**

**COASTER**  
FINE FURNITURE

**STEP 7**




**STEP 8**




ITEM: **950448BLK**

**STEP 9**




**STEP 10**




ITEM: **950448BLK**

**COASTER**  
FINE FURNITURE

**STEP 11**






**STEP 12**





ITEM: **950448BLK**

**STEP 13**

**COASTER**  
FINE FURNITURE




**STEP 14**




ITEM: **950448BLK**

**COASTER**  
FINE FURNITURE

## STEP 15







## STEP 16





ITEM: 950448BLK

## STEP 17







## STEP 18




ITEM: **950448BLK**

**STEP 19**


**COASTER**  
FINE FURNITURE



**STEP 20**  
**COMPLETE**



ITEM: 950448BLK



Note : Dimension tolerance  $\pm 5\%$


**ANTI-TIPPING INSTALLMENT INSTRUCTIONS**  
**FURNITURE TIPPING RESTRAINT****WARNING**

Injury may result from tipping furniture.  
This restraint may protect against tipping furniture.  
Do not allow children to climb on furniture.  
This restraint is not a substitute for proper adult supervision.  
Failure to detach this restraint before moving the furniture may result in injury and damage.


This restraint must be screwed to a wood stud on the wall, using the long screw provided.

**STEP 1**

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.

**STEP 2**

Locate the wood stud on the wall, and secure the other bracket, 2 inches below the back of the unit.

**STEP 3**

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end, and drag it through, until the slack is removed. Ensure that the strap is securely laced and locked.

