

COASTER[®]
FINE FURNITURE

DONNY
OSMOND **home**[™]
BY DONNY & DEBBIE OSMOND

107143

DINING CHAIR

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



www.coastercompany.com


Assembly Instruction

ASSEMBLY TIPS:

- 1.Remove hardware from and sort by size.
- 2,please check to see that all hardware and parts are present prior to start of assembly.
- 3,please follow attached instructions in the same aequence as numbered to assure fast & easy assembly

△ Warning !

- 1.Don't attempt to repair or modify parts that are broken or defective,please contact the store immediately
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME PER UNIT: 10 MINUTES

PARTS IDENTIFICATICON:

HARDWARE IDENTIFICATICON:

A	SEAT AND BACK		1PC
B	FRAME		1PC

ITEM	DESCRIPTION	SKETCH	MEAS	QTY
1	ALLEN KEY		4MM	1
2	BOLT 1		M6*16	2
3	BOLT 2		M6*35	2
4	FLAT WASHER		Φ6*20*1.5	4

