COASTER_{FINE FURNITURE}®

101811

BAR TABLE

ASSEMBLY INSTRUCTION COASTER FINE FURNITURE



www.coasterfurniture.com

Assembly Instruction

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior start of assembly.
- $3.\,\mathrm{Please}$ follow attached instruction in the same sequence as numbered assure fast & easy assembly.

▲Warning!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.





ASSEMBLY TIME PER UNIT: 20 MINUTES

HARDWARE LIST:

NO.	DESCRIPTION	FIGURE	QTY
1	∅1/4 ″ X1/2 ″ Bolt		8 PCS
2	∅10.5*∅7.0*1.5 Lock Washer		20 PCS
3	∅13.0*∅7.0*1.5 Flat Washer	©	20 PCS
4	∅1/4″X3/4″ Bolt		12 PCS
5	∅35*∅8*3.0 Washer	0	1 PC
6	M8 Bolt	9	1 PC
7	4.0mm ALLEN KEY		1 PC


PARTS LIST:

E. Bottom Stretcher

A. Table Top	1 PC
B.Adjustable Lever	1 PC
C. Leg	4 PCS
D. Upper Stretcher	1 PC

www.coasterfurniture.com

1 PC



www.coasterfurniture.com