


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

300261F (B1&B2) Full Bed

REVISION 0: 07/30/2014 REVISION 1: 08/09/2019

ITEM: 300261F (B1&B2)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)



1PC

1PC

RIGHT HEADBOARD LEG



1PC

B2 (BOX 2)

BED SLAT



RIGHT FOOTBOARD **LEG**



BED SLAT SUPPORT WITH LEVELER



FOOTBOARD PANEL



BED RAIL

2PCS HB 300261F (B1) FROM BOX 1

COMPLETE

HEADBOARD



LEFT FOOTBOARD LEG

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 300261F (B1)

BOLT

6PCS

1PC

ALLEN WRENCH (M4 x 60mm - BLK)



1PC

LOCK WASHER 2 (20mm - RBW)

(JCBC M6 x 50mm - RBW)



6PCS

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 300261F (B2)

FLAT HEAD SCREW (CSK M4 x 32mm - RBW)



8PCS

SMALL ALLEN **WRENCH** (M4 x 100mm - BLK)



1PC

BOLT (JCBC M6 x 40mm - RBW)



BIG ALLEN WRENCH (M5 x 70mm - BLK)

1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:300261F (B1&B2)



ASSEMBLY INSTRUCTIONS


STEP 1




**BACK VIEW

IF PURCHASE HEADBOARD ONLY, SKIP BELOW STEPS

STEP 2



IF PURCHASE HEADBOARD ONLY, SKIP BELOW STEPS




ITEM:300261F (B1&B2)



ASSEMBLY INSTRUCTIONS

STEP 6



STEP 7 COMPLETE

