

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509212 LOVESEAT

REVISION 0:10/10/2019

COASTERFURNITURE.COM

PAGE 1 OF 3

ITEM: 509212

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:


COASTER

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION

A

BASE

LEG

1PC

4PCS


В

I HADDWADE DACKACE


Z	HARD	WARE	PACKA	IGE

NO	DESCRIPTION	FIGURE	Q'TY
(1)	SCREW o10MM*29MM	\\	16PCS
(2)	SHORT BOLT		8PCS
(3)	ALLEN WRENCH		1PC


















ITEM: 509212





Note: Dimension tolerance ±5%

COASTERFURNITURE.COM