



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

**509251
SOFA**

REVISION 0:09/23/2019

COASTERFURNITURE.COM

PAGE 1 OF 3

ITEM: 509251

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 15 MINUTES


PARTS IDENTIFICATION

A		BASE	1PC
B		BACK	1PC
C		LEG	4PCS


STEP 1





STEP 2




STEP 3



STEP 4



ITEM: 509251



Note : Dimension tolerance $\pm 5\%$

COASTERFURNITURE.COM