

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509252 LOVESEAT

REVISION 0:09/23/2019

COASTERFURNITURE.COM

ITEM: 509252

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:


COASTER

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION





BASE 1PC


BACK


1PC

C LEG 4PCS














Note : Dimension tolerance ±5%

COASTERFURNITURE.COM