

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

551005 CORNER

REVISION 0:09/28/2019

COASTERFURNITURE.COM

ITEM: 551005

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:


COASTER

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 5 MINUTES


PARTS IDENTIFICATION

A CORNER 1PC

B LEG 4PCS


STEP 1
















Note: Dimension tolerance ±5%

COASTERFURNITURE.COM