


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

723609
SOFA TABLE

ITEM: 723609



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 40 MINUTES

PARTS IDENTIFICATION

A	TOP GLASS		1PC
B	TOP FRAME		1PC
C	SIDE FRAME		2PCS
D	WIDE CROSSBAR		4PCS
E	THIN CROSSBAR		4PCS
F	SUPPORT CROSSBAR		2PCS

ITEM: 723609


ASSEMBLY INSTRUCTIONS



PARTS IDENTIFICATION

G

BOTTOM CROSSBAR



2PCS

HARDWARE IDENTIFICATION

1

SHORT BOLT
(1/4" x 12mm)



24PCS

2

MEDIUM BOLT
(1/4" x 18mm)



8PCS

3

LONG BOLT
(1/4" x 45mm)



8PCS

4

SUCTION CUP
(ϕ 10mm)



4PCS

5

CAP
(20 x 20mm)



4PCS

6

ALLEN WRENCH
(4mm)




1PC

ITEM: 723609




ASSEMBLY INSTRUCTIONS

STEP 1 Do not tighten until each step is completed or instructed.




STEP 2




ITEM: 723609

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4



ITEM: 723609 ASSEMBLY INSTRUCTIONS

Product Size : 1200 X 400 X 762 H (MM)

Product Size : 47 $\frac{1}{4}$ " X 15 $\frac{3}{4}$ " X 30"



Note : Dimension tolerance $\pm 5\%$